JVC

LT-32DS6BJ LT-26DS6BJ
LT-32DS6SJ LT-26DS6SJ

WIDE LCD PANEL TV INSTRUCTIONS



DynaPiX
Powered by D.I.S.T.

InteriArt

HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE

T-V LINK

DVB®
Digital Video Broadcasting

Trade Mark of the DVB Digital Video Broadcasting Project (1991 to 1996) Number : 3476, 3477, 3478, 3479

LCT1847-001A-U

Expanding the world of

beautiful images



Contents

*In this manual,
ATV : analogue terrestrial broadcasting (VHF/UHF)
DTV : digital terrestrial broadcasting (DVB-T)

First things first!

- Warning 4

Getting started

- Names of all the parts 6
- Basic connections 8
- Connecting external devices 10
- Initial settings 12
- Editing DTV channels 14
- Editing ATV channels 16

Let's try it out

- Enjoying your new TV! 18
  · TV / Teletext / EPG / Video / Menu
- Watching TV 20
- Using EPG 22
- Viewing teletext 24
- Watching videos / DVDs 26

Try the advanced features

- Useful functions 28
  · Multi-picture / Favourite channel
  · Sleep timer / Child lock

Just the way you like it

- Customising your TV 32
- Using DTV 34
- Advanced picture adjustment 40
  · Reduce noise / Watch a more natural picture
  · Set the aspect ratio, etc.

When you have trouble

- Troubleshooting 42
- CH/CC List 45
- Technical information 46
- Specifications 47

Warning

Please follow all the guidelines below

Never cut or damage the power cord!

- If the AC plug is not the right shape, or the power cord is not long enough, use an appropriate plug adapter or extension cable. (Consult your retailer.)



- If you have cut or damaged the power cord. ➡"Technical information" (P. 46)
- To change the fuse in UK plugs ➡"Technical information" (P. 46)

Never try to repair the TV yourself!

➡If the problem cannot be solved in "Troubleshooting" (P. 42), unplug the power cord and contact your retailer.

Never place anything on the TV!

- Placing liquids, naked flames, cloths, paper, etc. on the TV may cause a fire.



Follow this manual regarding setup!

- Connect only to a 110-240V, 50/60Hz AC outlet.

Unplug the power cord when going out!



- The power buttons on the remote control and the TV unit can not completely turn off the TV. (Make appropriate arrangements for bedridden people.)

Never insert objects into the cabinet openings!

- It may cause a fatal electric shock. Take care when children are near.

■For more details on installation, usage and safety ➡ Consult your retailer

Never expose to rain or moisture!



- To prevent fire or electric shock, never allow liquids to enter the unit.

Do not allow the TV to fall!

- Do not rest your elbows on, or allow children to hang from the TV.
  There is a risk that the TV will fall and cause injuries.

If the TV is damaged or behaving strangely, stop using it at once!

➡ Unplug the power cord and contact your retailer.

Hold the TV so as not to scratch the screen!

- Do not touch the screen when carrying the TV.

Do not carry the TV on your own!

- In order to prevent accidents, ensure that the TV is carried by two or more people.



When attaching the TV to the wall, use the optional JVC wall mounting unit!

- Consult a qualified technician.
- See the included manual on mounting procedures.
- JVC assumes no responsibility for damage due to improper mounting.

Never dismantle the rear panel!

- It may cause an electric shock.

Never obstruct the ventilation holes!

- It may cause overheating or a fire.

Handle LCD panel with care!

- Use a soft, dry cloth when cleaning.

Never listen to headphones at high volume!

- It may damage your hearing.

Names of all the parts



Remove the terminal covers



- If the cover cannot be closed due to the cables being in the way
  ➡ Do not force the cover to close (leave it open).
- Connecting terminals on the back of the TV ➡ Connecting External devices (P. 10)

Change the direction of TV



Check accessories

Remote control
(RM-C1813H)

AA/R6 Batteries
(For confirming the TV works)

Mute

Power On/Off

Switch between VCR/TV/DVD (P. 26)

Change the channel/page

Channel information (P. 20)

Watch video, etc. (P. 26)

To ATV/DTV

To menu (P. 32)

Select and confirm settings in menus

To the previous channel

To teletext (P. 24)

Volume

Change the channel/page

The coloured buttons can perform different functions according to the situation.

■When viewing teletext (P. 24)

Follow on-screen instructions.

■Other uses



Follow instructions in on-screen guides.

■When watching TV/Video

Change the aspect ratio (P. 20)

Turn on 3D sound (P. 20)

ZOOM 3D

Take a snapshot of the screen (P. 20)

View in multi-picture mode (P. 28)

■When watching DTV

View subtitles (P. 20)

View the electronic programme guide (EPG)(P. 22)

SUB TITLE GUIDE

■When watching ATV (P. 16)

when viewing teletext (P. 24)

SUB TITLE GUIDE F.T/L TOP MENU

■When choosing a favourite channel (P. 29)

■When operating a JVC VCR or DVD (P. 26)

■Insert the batteries

Use two AA/R6 dry cell batteries.
Insert the batteries from the - end, making sure the ⊕ and ⊖ polarities are correct.



Basic connections

Please read the user manuals of each device carefully before setup.
It is necessary to connect an aerial to watch TV.

■Connect with other devices ➡ "Connecting external devices" (P. 10)

Connect the aerial



●After all the connections have been made, insert the plug into an AC outlet.

Care when setting

■Power requirements

●Connect the power cord only to a 110-240V, 50/60Hz AC outlet.

■When attaching the TV to the wall, use the optional JVC wall mounting unit

●Consult a qualified technician.
●See the included manual on mounting procedures.
●JVC assumes no responsibility for damage due to improper mounting.

■Installation requirements

●To avoid overheating, ensure the unit has ample room.



Connect a VCR / DVD recorder



- After all the connections have been made, insert the plug into an AC outlet.
- Connect T-V LINK compatible recording device to EXT-2.
- T-V LINK ➡ "What is T-V LINK?" (P. 12)

Watch pay-per-view

Contract with a broadcasting company beforehand.

①Unplug the power cord

②Insert the Viewing Card into the CAM.

③Insert the CAM.

④Plug the power cord, and turn the power on.

- Set pay-per-view ➡ (P. 38)

- The CAM and Viewing Card will be sent by the broadcasting company after contracting with them.



Connecting external devices

You can connect many different devices to the rear panel of the TV.
Please read the user manuals of each device before setting up.
(Connecting cables are not supplied with this TV.)



VCR / DVD / other devices

⇨ : signal direction



■Connect DVI devices
➡ (P. 46)

■T-V LINK ➡(P. 12)

EXT-1 Watching videos

Output ⬆	Input ⬇
· Composite signal · Sound L / R	· Composite signal / RGB / S-VIDEO · Sound L / R

● Use S-VIDEO ➡ "S-IN" (P. 27)

EXT-2 Dubbing videos Using T-V LINK

Output ⬆	Input ⬇
· Composite signal · S-VIDEO (only for DTV) · Sound L / R	· Composite signal / RGB / S-VIDEO · Sound L / R
· T-V LINK	

● Use S-VIDEO ➡ "S-IN" (P. 27)
● Use DTV S-OUT ➡ "S-OUT" (P. 27)
● Select dubbing sources
➡ "DUBBING" (P. 27)
● Connect a decoder
➡ "DECODER (EXT-2)" (P. 33)

EXT-3 Watching videos

Output ⬆	Input ⬇
	· Composite signal / S-VIDEO · Sound L / R

EXT-4 Watching DVDs

Output ⬇	Input ⬆
	· Component signal (P. 47) · Sound L / R

● Component auto select ➡ (P. 33)

EXT-5 Connecting HDMI devices

Output ⬆	Input ⬇
	· HDMI signal (P. 47)

● HDMI setting ➡ (P. 33)

AUDIO OUT
Listening to the TV on external speakers

Output ⬇
· Sound L / R

Initial settings

Register DTV/ATV channels on TV. These channels can be edited later.
(In this manual, digital broadcasting is indicated as DTV, and analogue broadcasting as ATV.)



■To the previous screen ➡ BACK

■Exit ➡ TV/DTV

■If the "JVC" logo does not appear or if you wish to make changes later

➡DTV : "Automatic Seach" (P. 38)
ATV : "AUTO PROGRAM"(P. 33)

What is "T-V LINK"?

Connecting the TV to a T-V LINK compatible device allows :

- ATV Channels on the TV to be instantly registered on the device.
- The "DIRECT REC" function to be used.
  ➡"Technical information" (P. 46)

■T-V LINK variations

"T-V LINK" (JVC) "Q-LINK" (Panasonic)
"Megalogic" (Grundig) "Data Logic" (Metz)
"SMARTLINK" (Sony) "Easy Link" (Philips)

1 Begin

- Shown only when powering on for the first time.
- The power button on the remote control can also be used.

2 Automatically register DTV channels



3 Check what was registered

■Edit DTV channels

➡ 5 in "Editing DTV channels" (P. 14)

■Confirm



4 Automatically register ATV channels





- If "ACI START" appears, select and start settings. (This will set up cable television channels.)
  ➡ "What is ACI (Automatic Channel Installation)?" (P. 46)

5 Check what was registered



■Edit ATV channels

➡ 5 in "Editing ATV channels" (P. 16)

■Confirm

6 Finish



■When using T-V LINK

- If "FEATURE NOT AVAILABLE" appears :
  ➡ Is a T-V LINK compatible device connected to EXT-2?
  ➡ Is the device turned on?

■When not using T-V LINK

Editing DTV channels

Edit the channels registered with "Automatic search" in "Initial settings" (P. 12).

When coming from "Initial settings" (P. 12), skip to 5.



1 Select DTV

TV/DTV

2 Display the menu bar

MENU

3 Select "DTV"





4 Select "Edit PR List"





5 Select a channel



6 Edit

7 Finish

MENU

■To the previous screen

BACK

■Exit

MENU

■Tips for operation

Confirm the channel picture

Select

Delete a channel

Delete

Edit a channel name

Edit Name

Stop Children from watching specific channels

Lock

Register your favourite channel

Favourites

①Select "Select"



①Select "Delete"

②Select "Yes"



①Select "Edit Name"

②Change the name



③Decide



①Select "Lock"

②Enter PIN code



●Default is "0000".
➡"Change the PIN code" (P. 37)

●To release, repeat the same steps.

①Select "Favourites"



●To release, repeat the same steps.

●Move through only your favourite channels
➡"Favourite Mode" (P. 37)

Editing ATV channels

Edit the channels registered with "AUTO PROGRAM" in "Initial settings" (P. 12).

When coming from "Initial settings" (P. 12), skip to 5.



1 Select ATV

TV/DTV

2 Display the menu bar

MENU

3 Select "SET UP"





4 Select "EDIT/MANUAL"





5 Select a row





■To the previous screen

➡ BACK

6 Edit

■Exit

➡ MENU

7 Confirm settings

8 Finish



■When using T-V LINK

■When not using T-V LINK

TV/DTV

● If "FEATURE NOT AVAILABLE" appears :
  ➡ Is a T-V LINK compatible device connected to EXT-2?
  ➡ Is the device turned on?

● T-V LINK ➡ (P. 12)

Move a channel's position
MOVE

Edit a channel name
ID

Insert a channel
INSERT

Delete a channel
DELETE

Register a new channel
MANUAL

①Begin ②Select a destination ③Finish



①Begin ②Enter a channel name



■When selecting a preset name from the ID LIST



■When manually naming a channel



①Begin ②Enter a CH number ③Set



●CH/CC List ➡ (P. 45)
●In Ireland, slect CH/CC with ▲▼.

●Receives the broadcast signal.

①Delete



①Begin ②Search for a channel



●Auto-search begins, and the nearest frequency is imported.
➡Repeat the previous steps until the desired channel is displayed

③Set



■Picture fine tuning ➡ (yellow) ◯ / (blue) ◯

Enjoying your new TV!



Watching TV

PAGE 20

- View channel information
- Change the aspect ratio
- Enjoy 3D sound
- Take snapshots of the screen





Viewing teletext

PAGE 24

- Enlarge the text
- To the index page
- Hold the current page
- Switch briefly between teletext and TV
- Bookmark your favourite pages



TV and Text tmode

Using EPG

PAGE 22

- View the programme list for 8 days
- Search from a genre
- Reserve a programme to watch / record



PAGE 26

Watching videos / DVDs

AV

- Watch high quality video (S-VIDEO)
- Name connected devices
- Dub videos

PAGE 32

Personal preferences

MENU

- Adjust the picture
- Adjust the sound



- Use DTV
  (timer-record / configuration / channel settings, etc.)
- Basic settings
  (channel settings, etc.)
- Advanced settings
  (sleep-timer / child lock, etc.)



Watching TV

1 Power on

The green power lamp on the TV lights.

- Press again to turn the screen off and put the TV into standby mode.

2 Select ATV/DTV

TV/DTV

- DTV : Digital broadcasting
  ATV : Analogue broadcasting

3 Select a channel

① ② ③
④ ⑤ ⑥
⑦ ⑧ ⑨
⑩

■Move up or down a channel

- With DTV, you can select only from your favourite channels ➡ (P. 37)

■To the previous channel

➡

■Mute

■Volume

■Switch between stereo/mono/ bilingual broadcasting
➡ "STEREO/ Ⅰ · Ⅱ" (P. 32)

Note

- To completely turn off the TV, unplug the AC plug.
- Watch pay-per-view ➡ (P. 38)
- Add a new station ➡ (P. 38)

Basic operations using the side buttons



Channel information and clock
INFORMATION

View subtitles
SUBTITLE
(DTV)

Change the aspect ratio
ZOOM

Enjoy ambient sound
3D SOUND

Take snapshots of the screen
FREEZE

■When DTV is selected

■When ATV is selected



PR LIST

●Channels registered in "Initial settings" will appear here.

Channel information

Time (in case of having viewed teletext)

(No indication)

●Select a page ➡

●Select and view a channel ➡ 

SUB TITLE

●Shown only when subtitles exist

●To avoid subtitle recording, turn the subtitles off before recording.

■Turn off subtitles

SUB TITLE

ZOOM







Move the picture with ▲ or ▼ while this bar is displayed

●When set to AUTO, the aspect ratio will turn to the ratio obtained from the information the TV received. Without receiving aspect information, it will be the setting in "4:3 AUTO ASPECT" (P. 40).

●Not available in PC mode or 1080i (1125i)/720p (750p) signals.

3D



HIGH : For stereo sound

LOW : For stereo sound (when the sound distorts in HIGH mode)

MONO : For mono sound (emulates a stereo-like sound)

OFF : Turns off 3D SOUND





●Not available when the SUB-PICTURE is displayed, or when in PC mode.

●You cannot save or export the snapshot.

■Cancel

➡Press again, or change the channel

Using EPG (Electronic Programme Guide)

You can find a programme from an eight-day programme guide, check its information, and make a reservation.

1 Select DTV

TV/DTV

2 Display EPG

GUIDE

EPG


Electronic Programme Guide 05:27 20/10/2004
GENRE All
20/10 2. BBC TWO 04:00- History: Britain 1750-1900
21/10 7. BBC THREE 06:00- Big Cook Little Cook
22/10 30. CBBC Channel 06:20- Tots TV
23/10 40. BBC NEWS 24 06:30- Bobinogs
24/10 51. BBCi 06:45- Wide Eye
25/10 89. BBC R Scotland 07:00- Snailsbury Tales
26/10 90. BBC R n Gaidheal 07:15- Arthur
27/10 800. 16:9monoscope 07:30- I Love Mummy
04:00-6:00 History: Britain 1750-1900
Secondary Schools, How industrialisation changed the day-to-day lives of the British people.

3 Find a programme



Select a date → Select a channel → Select a programme

● You can check programme content.

■ Close EPG → GUIDE

■ Search from a genre

①While EPG is displayed...

Display the Genre List (green)



②Select a genre




Electronic Programme Guide 05:43 20/10/2004
GENRE Movies
20/10 1. BBC ONE 00:15- Last Embrace
21/10 2. BBC TWO
22/10 7. BBC THREE
23/10 40. CBBC Chennel
24/10 40. BBC NEWS 24
25/10 51. BBCi
26/10 89. BBC R Scotland
27/10 90. BBC R n Gaidheal
03:25-6:00 BBC News 24
BBC ONE joins the BBC's rolling news channel for a night of news, with bulletins on the hour and the headlines every 15 minutes.

③Find a programme



● Only programmes in the selected genre are displayed.

Reservations

Reserve a programme to watch

Programme-view setting

After ❸


Electronic Programme Guide 06:06 20/10/2004
GENRE All
20/10 2 BBC TWO 06:00- Big Cook Little Cook
21/10 7 BBC THREE 06:20- Tots TV
22/10 30 CBBC Channel 06:30- Bobinogs
23/10 40 BBC NEWS 24 06:45- Wide Eye
24/10 51 BBCi 07:00- Snailsbury Tales
25/10 89 BBC R Scotland 07:15- Arthur
26/10 90 BBC R n Gaidheal 07:30- I Love Mummy
27/10 800 16:9monoscope 07:55- Newsround
04:00-6:00 History: Britain 1750-1900
Secondary Schools, How industrialisation changed the day-to-day lives of the British people.



- At the start time, the channel will automatically change.
- If the TV's power is off at the start time, nothing happens.

■Cancel the reservation ➡ Select the reserved programme and press "OK"

After ❸

(red)


REC TIMER 06:02 20/10/2004
No. Name Start End Date Mode
1 BBC ONE 00:00 00:00 01/01/2004 Inactive
2 BBC ONE 00:00 00:00 01/01/2004 Inactive
3 BBC ONE 00:00 00:00 01/01/2004 Inactive
4 BBC ONE 00:00 00:00 01/01/2004 Inactive
5 BBC ONE 00:00 00:00 01/01/2004 Inactive
6 BBC ONE 00:00 00:00 01/01/2004 Inactive
7 BBC ONE 00:00 00:00 01/01/2004 Inactive
8 BBC ONE 00:00 00:00 01/01/2004 Inactive
9 BBC ONE 00:00 00:00 01/01/2004 Inactive
10 BBC ONE 00:00 00:00 01/01/2004 Inactive
Name BBC TWO
Start 06:30
End 06:45
Date 20/10/2004
Mode Once



- Prepare for recording

·Set the recording device to external input mode before the start time.
·For T-V LINK incompatible devices, manually set the timer on the device. For details, refer to the manual of the recorder.
·Make sure that recording times on the recording device do not overlap with recording times on the TV.
·When Rec Timer has been set, the power lamp on the TV will :
Start blinking 3 minutes before the start time (green or red)
Light during recording (green or orange)
·Some T-V LINK compatible DVD recorders may not work correctly.

■Exit ➡ Press "MENU"

Reserve a programme to record

Programme-record setting

■Confirm the reservation


Electronic Programme Guide 06:06 20/10/2004
GENRE All
20/10 2 BBC TWO 06:00- Big Cook Little Cook
21/10 7 BBC THREE 06:20- Tots TV
22/10 30 CBBC Channel 06:30- Bobinogs
23/10 40 BBC NEWS 24 06:45- Wide Eye
24/10 51 BBCi 07:00- Snailsbury Tales
25/10 89 BBC R Scotland 07:15- Arthur
26/10 90 BBC R n Gaidheal 07:30- I Love Mummy
27/10 800 16:9monoscope 07:55- Newsround
04:00-6:00 History: Britain 1750-1900
Secondary Schools, How industrialisation changed the day-to-day lives of the British people.



- At the start time, the channel will automatically change and the device connected to EXT-2 will begin recording the programme.

■Change a reservation

➡"MENU" ➡ " DVB " ➡ "Rec Timer"




REC TIMER 06:02 20/10/2004
No. Name Start End Date Mode
1 BBC ONE 00:00 00:00 01/01/2004 Inactive
2 BBC ONE 00:00 00:00 01/01/2004 Inactive
3 BBC ONE 00:00 00:00 01/01/2004 Inactive
4 BBC ONE 00:00 00:00 01/01/2004 Inactive
5 BBC ONE 00:00 00:00 01/01/2004 Inactive
6 BBC ONE 00:00 00:00 01/01/2004 Inactive
7 BBC ONE 00:00 00:00 01/01/2004 Inactive
8 BBC ONE 00:00 00:00 01/01/2004 Inactive
9 BBC ONE 00:00 00:00 01/01/2004 Inactive
10 BBC ONE 00:00 00:00 01/01/2004 Inactive
Name BBC TWO
Start 06:30
End 06:45
Date 29/10/2004
Mode Once

Change with ◀▶

Enter using the numerical keypad

Change with ◀▶ (Once/Daily/Weekly)

■Cancel a reservation

➡"MENU" ➡ " DVB " ➡ "Rec Timer"





Viewing teletext

This TV can display TV broadcasts and teletext on the same channel in two windows.



1 Select ATV/DTV

TV/DTV

2

■When DTV is selected

➡Operate according to the screen indications

■When ATV is selected

➡Enter a teletext page

1 2 3
4 5 6
7 8 9
0

●Move up or down a page

up

P

down

●View sub-pages

OK

to sub-page

01 02 ⟷ 01 02 .....

■When ATV is selected

When watching TV



Bookmark your favourite page

LIST MODE

(ATV)

1 F.T/L Display your favourites list

(RED) (GREEN) (YELLOW) (BLUE)

??? ??? ??? ???

2 Select a coloured button to save your page to

??? ??? ??? ???

(red) (green) (yellow)(blue)

3 Enter the number of the page to save

??? 124 ??? ???

1 2 3
4 5 6
7 8 9
0

4 Save

■Recall your favourite page ➡ Press the coloured button as in step 2

Hold the current page

HOLD
(ATV)

Hold the current page

■Release ➡ Press again

Reveal hidden pages

REVEAL
(ATV)

Display hidden information
(answers to quizzes, etc)

1 + 2 =
2 x 3 =

↔

1 + 2 = 3
2 x 3 = 6

Enlarge the text

SIZE
(ATV)

Double the size of the displayed text

TEXT
SIZE

To the index page

INDEX
(ATV)

Returns to page "100"
or a previously designated page

Switch briefly from teletext to TV

CANCEL
(ATV)

Leave the current page open,
while you switch to watch TV

P233
TEXT ---
TEXT ---

↔

P233

●Useful when running a page search.

Watching videos / DVDs



Operate the VCR (DVD)

■To TV

1 Select the video source

E.g. For EXT-1



*1 : Only appears when AV has been registered as a channel.
*2 : Switches to DTV.

2 Operate the connected device and play a video

Operate JVC VCRs and other devices

1 

DVD players

VCRs and DVD recorders

2

Turn on the device

3 Select a channel (VCR mode)



●Some models of JVC devices cannot be operated with this remote control.

Advanced functions



1 MENU Display the menu bar

2 Select "SET UP"



Select "EXT SETTING"



Switch to S-VIDEO input/output

S-IN

S-OUT (DTV)

①Select the EXT connected to S-VIDEO

②Set S-VIDEO input



- The device selection display will change from E1 to S1.
- S-OUT is not available when EXT-2 receives an RGB input.

■Cancel this mode ➡ Press (yellow) in ② again

■Set the S-OUT ➡ Cancel S-IN at "EXT-2", then select "DTV" and press yellow button. (available only for DTV)

Edit names of connected devices

ID LIST

①Select an EXT to assign a name to

②Show the name list



③Select a name from the list



■Clear the name ➡ Select the blank space in ③

Set up dubbing on EXT-2

DUBBING

①Select the arrow

②Select the dubbing source



■Record DTV with S-VIDEO ➡ Set S-OUT at "DTV".

Useful functions

Watch in multi-picture mode

MULTI-PICTURE

Select the number of screens



Selecting " 1 " returns to normal viewing mode

- Not available in PC mode.

■Watch in dual-picture mode

E.g. You can watch TV and video at the same time.

(For 1080i, 720p signal)



- Switch between the sound sources ➡
- Change the channel
  - ➡ (Main)
  - ➡ (Sub)

■Select a channel in 12-screen mode (ATV)

All registered channels are displayed as still images.



Only the selected frame has a moving picture.

- Move up or down a page ➡
- Not available when in DTV channels or EXT-5 input.



Register a channel to a button

FAVOURITE CHANNEL

(ATV)

While the channel is displayed



(For 3 seconds)

Press the number to register it on

① ② ③ ④



- "NOT AVAILABLE" is displayed: Already registered

Disappears after a few seconds

■Recall the favourite channel

Press the number you registered

① ② ③ ④



- Customisations (P. 32) to the picture of a favourite channel get saved as well.
- "NOT MEMORY" is displayed: Not registered

■Check your favourite channels ➡ Press (i) and confirm that the channels you have registered have a 🕮 beside them

■Delete a favourite channel

➡"MENU" ➡ " " ➡ "FEATURES" ➡ "FAVOURITE SETTING"



select

Delete (blue)



Useful functions

Set a time for the TV to turn itself off

SLEEP TIMER

1

2



3



4



■Cancel

➡Set the time to "0" in step 4

■Remaining time

➡You can confirm the remaining time at step 4, after repeating this process.



Stop children from watching specific channels

CHILD LOCK

(ATV)

1 MENU

2 FEATURES





①select "FEATURES"

②next

3



select "CHILD LOCK"

4

①enter an "ID NO." (a secret number of your choice)

②to the next column

③set

5



select a channel to lock

6 (blue)



■Lock more channels

➡ Repeat steps 5 and 6

7

■Release a channel ➡ Press (blue) again in step 6

■View a locked channel ➡ Use the numerical buttons to enter the channel number. When 🔒 appears, press (i) and enter your "ID NO.". (If you forget your "ID NO.", check it in step 4.)

Customising your TV



1 Display the menu bar

MENU



2 Select a menu



3 Select an item



4 Adjust/Configure





■When adjusting with the sliding-bar



■When selecting from presets



●Some items have a sub-menu.

■To the previous screen

■Exit

●The menu disappears after one minute of inactivity.

Menu	Item	Adjustments / Configurations
PICTURE	PICTURE MODE	Picture mode (BRIGHT / STANDARD / SOFT)
	BRIGHT-1	Backlight brightness (Darker ⇔ Brighter)
	CONTRAST	Contrast (LOWER ⇔ HIGHER)
	BRIGHT-2	Brightness (DARKER ⇔ BRIGHTER)
	SHARP	Sharpness (SOFTER ⇔ SHARPER)
	COLOUR	Colour (LIGHTER ⇔ DEEPER)
	HUE	Tint (REDDISH ⇔ GREENISH)
	COLOUR TEMP.	Colour temperature (WARM / NORMAL / COOL)
	FEATURES	Finer picture adjustments (P. 40)
SOUND	STEREO / I · II	Mode / Language (∞ : STEREO / ○ : MONO / Ⅰ : SUB1 / Ⅱ : SUB2)
	BASS	Low tones (WEAKER ⇔ STRONGER)
	TREBLE	High tones (WEAKER ⇔ STRONGER)
	BALANCE	Speaker balance (LEFT STRONGER ⇔ RIGHT STRONGER)
	3D SOUND	Ambience level (HIGH / LOW / MONO / OFF)
	A.H.B.	Emphasize the bass sound (ON / OFF)
	BBE *	Sound enhancement technology (ON / OFF)
	SPEAKER	Output (TV SOUND / Sound from CENTRE CH input)
FEATURES	SLEEP TIMER	Timer for turning off the TV (P. 30)
	CHILD LOCK	Stop children from watching specific channels (P. 31)
	APPEARANCE	Format for displaying the channel number (TYPE A / TYPE B / TYPE C / TYPE D)
	BLUE BACK	Display a blue screen and mute the sound when the signal is weak or absent (ON / OFF)
	FAVOURITE SETTING	Clear favourite channel settings (P. 29)
	ILLUMINATION	Lights illumination lamp (P.6) while the power is turned on (BRIGHT / SOFT / OFF)
SET UP	AUTO PROGRAM	Select the country of installation, automatically register channels (P. 12, 4)
	EDIT / MANUAL	Change registered channels or add new ones (P. 16)
	DECODER(EXT-2)	For when connected to VCR with T-V LINK (ON / OFF)
	COMPONENT AUTO SELECT	Changes the TV input to EXT-4 when the component signals are input to EXT-4. (ON/OFF) (Not available when viewing DTV or PC)
	EXT SETTING	For use with video players and other devices (P. 27)
	HDMI SETTING	SIZE (AUTO / 1 / 2) AUDIO (AUTO / ANALOGUE / DIGITAL)
	ATTENUATOR	For when the picture is not displayed because of too strong radio waves (ON/OFF)

● Other settings · Change the aspect ratio ➡ "ZOOM" (P. 20)
· Turn on 3D SOUND ➡ "3D SOUND" (P. 20)

* BBE licence ➡ (P. 46)

Using DTV

Timer-record setting

DTV original function and setting, such as a recorder-linked timer-record setting, can be selected from the DTV menu.



1 Select DTV

TV/DTV

2 Display the menu bar

MENU

3 Select "DTV"





4 Select an item





- Rec Timer ➡ "Recording using timer setting" (P. 34)
- Configuration ➡ "Change AV settings" (P. 36)
- Edit PR List ➡ "Editing DTV channels" (P. 14)
- Installation ➡ "Reset channel/Register a new channel/Initialise the DTV settings" (P. 38)
- Common Interface ➡ "Set pay-per-view" (P. 38)

■To the previous screen

➡ BACK

■Exit

➡ MENU

- The menu disappears after one minute of inactivity.

- DTV menu cannot be operated with the front panel buttons.

Recording using timer setting

Rec Timer

1 Select an "Inactive" column


REC TIMER 06:02 20/10/2004
No. Name Start End Date Mode
1 BBC ONE 00:00 00:00 01/01/2000 Inactive
2 BBC ONE 00:00 00:00 01/01/2000 Inactive
3 BBC ONE 00:00 00:00 01/01/2000 Inactive
4 BBC ONE 00:00 00:00 01/01/2000 Inactive
5 BBC ONE 00:00 00:00 01/01/2000 Inactive
Channels
Start to End
Dates
Timer-record setting state
Active : timer set
Inactive : completed, cancelled



●Settings can be overwritten.

2 Input timer-record setting details


REC TIMER 06:02 20/10/2004
No. Name Start End Date Mode
1 BBC ONE 00:00 00:00 01/01/2004 Inactive
2 BBC ONE 00:00 00:00 01/01/2004 Inactive
3 BBC ONE 00:00 00:00 01/01/2004 Inactive
4 BBC ONE 00:00 00:00 01/01/2004 Inactive
5 BBC ONE 00:00 00:00 01/01/2004 Inactive
6 BBC ONE
7 BBC ONE
8 BBC ONE
9 BBC ONE
10 BBC ONE
Name BBC TWO
Start 06:30
End 06:45
Date 20/10/2004
Mode Once
Change with ◀▶
Enter using the numerical keypad
Change with ◀▶ (Once/Daily/Weekly)

3 Set



●A message will be displayed if you set past dates.
●The channel will be selected automatically at the set start time, and the recorder connected to EXT-2 will start recording.

●For more details about the timer-record setting, refer to the notice of
➡ "Prepare for recording" (P. 23)

■Cancel a timer-record setting

➡Select the column at step 1 and press ▶. (Mode will be changed to "Inactive")

■Change a timer-record setting

➡Select the column at step 1 and repeat steps 2 and 3.

Using DTV

AV setting

Available for changing subtitle languages for DTV, favourite channel selection, changing PIN code, and upgrading the tuner software.
Also, you can upgrade the tuner software as newer versions become available.



1 Select DTV

TV/DTV

2 Display the menu bar

MENU

3 Select "DTV"



4 Select an item





- Rec Timer ➡ "Recording using timer setting" (P. 34)
- Configuration ➡ "Change AV settings" (P. 36)
- Edit PR List ➡ "Editing DTV channels" (P. 14)
- Installation ➡ "Reset channel/Register a new channel/Initialise the DTV settings" (P. 38)
- Common Interface ➡ "Set pay-per-view" (P. 38)

■To the previous screen

➡

BACK

■Exit

➡ MENU

- The menu disappears after one minute of inactivity.

- DTV menu cannot be operated with the front panel buttons.

Change AV settings

Configuration

1 Select a configuration item





2 Change settings

■ Audio Language Subtitle : Change language
Favourite Mode : Channel selection method

Audio Language Subtitle	Switch languages (English / Welsh / Gaelic)
Favourite Mode	Select only DTV channels registered by using "Favourites"(P. 14) with ∧ ∨ (On/Off)

■ Receiver Upgrade : Upgrade tuner

Automatic Download	Automatically and periodically (Enabled/Disabled)
Search for New Version	Download now (Press "OK" button.)

■ Enter PIN code : Change PIN code

①Input the current code



- Default is "0000".
- If you forget the code
  ➡ Default the code in "Reset channel registration" (P. 38)

②Input a new code twice.



Using DTV

Registration and setting

Available for registration of DTV channels, initialisation of all DTV settings, and downloading software to use pay-per-view.



1 Select DTV

TV/DTV

2 Display the menu bar

MENU

3 Select "DTV"





4 Select an item





- Rec Timer ➡ "Recording using timer setting" (P. 34)
- Configuration ➡ "Change AV settings" (P. 36)
- Edit PR List ➡ "Editing DTV channels" (P. 14)
- Installation ➡ "Reset channel/Register a new channel/Initialise the DTV settings" (P. 38)
- Common Interface ➡ "Set pay-per-view" (P. 38)

■To the previous screen

➡ BACK

■Exit

➡ MENU

- The menu disappears after one minute of inactivity.

- DTV menu cannot be operated with the front panel buttons.

Reset channel registration

Register a new channel

Initialise the DTV settings

Installation

Set pay-per-view

Common Interface

1 Select an installation item



2 Change setting

Automatic Search : Reset channel registration

①Select "Yes"







●Displays "Edit PR List" (P. 14) after registering channels.

Manual Search : Register a new channel

①Enter a channel number





②Receive the channel



●When receiving is completed, a message will be displayed and the screen will return to ①.

Factory Setting : Initialise the DTV settings

①Select "Yes"





②Start channel registration



❸ in "Initial settings" (P.12)

Preparation : Set the CAM etc. after contracting with the broadcasting company
➡ "Watch pay-per-view" (P. 8)

①Select the broadcasting station



②Select "Software Download"





③Select "Yes"







●Use this menu for settings and contract content for pay-per-view.
➡ For details, consult your broadcasting company

Advanced picture adjustment

By default, the TV automatically adjusts itself for the best picture.



1 Display the menu bar

MENU

2 Select "PICTURE"



3 Select "FEATURES"



4 Select an item



E.g. DIGITAL VNR

■To the previous screen

➡ BACK

5 Change settings



E.g. DIGITAL VNR

■Exit

➡ MENU

●The menu disappears after one minute of inactivity.

6 Finish

To reduce noise



level

MIN	AUTO(LOW)	AUTO(HIGH)	MAX

: When the picture loses sharpness ⟷ : When noise appears

For natural-looking outlines



level

OFF	MIN	AUTO	MAX

: Function is turned off — : When noise appears ⟷ : When the picture loses sharpness

For smooth cinema film



OFF	ON	AUTO
: Function is turned off	: Function is always on	: Automatically adjusts

For natural-looking pictures



OFF	ON
: Function is turned off	: Maintain a natural colour balance

Fix bright/dark pictures



OFF	ON
: Function is turned off	: Make it easier to view bright / dark pictures

When there is no colour



①Select the screen to change settings on

MAIN	SUB
: Main picture	: Sub-picture in MULTI-PICTURE mode (P. 28)

②Select the colour system

PAL	NTSC 3.58	NTSC 4.43	AUTO
: Western Europe	: USA 3.58 MHz	: USA 4.43 MHz	: When watching videos, etc.

Set a default aspect ratio



Select a default aspect ratio for "AUTO" in "ZOOM" (P.20)

PANORAMIC	REGULAR	14:9 ZOOM
16 : 9	4 : 3	14 : 9

Troubleshooting

Severe noise or snow



- Is the TV connected correctly to the aerial?
- Change the direction of the aerial.
- Is the aerial or its cable damaged?
  ➡ Consult your retailer

Patterns, stripes or noise

- Is the aerial receiving interference from high-voltage power lines or wireless transmitters?
  ➡ Consult your retailer
- Are connected devices too close to the TV?
  ➡ Insert the minimum distance between the aerial and the cause of interference until no interference

Ghosting

(Doubling of images)

- Are you receiving interference from signals reflected off mountains or buildings?
  ➡ Adjust the direction of your aerial, or change to a good-quality directional aerial



I can't turn it on!

- Is the power cord connected to the AC outlet correctly?



The remote control doesn't work!

- Are the batteries flat?
- Are you more than 7 metres away from the TV?
- Is the "VCR/TV/DVD SWITCH" set to "TV"?
- When viewing teletext, the TV menu bar does not appear.
- Depending on the stability of the signal, there may be a time lag when changing channels.

	Problem	Actions	page
Basics	Not displayed (black screen)	●Is the ATV reception poor, too? ➡ Following the instructions in "Severe noise or snow" can solve this problem. ●Is there a DTV transmission tower nearby? ➡ Turn "ATTENUATOR" to "ON", since the radio waves are too strong. ●There may be problems at the antenna, radio waves, or the area you live in, where reception is bad. Consult your retailer.	42 33 –
	Remote control stops working	●Unplug TV, several minutes later plug it in again.	–
	DTV screen is frozen	●Hold down TV/AV and MENU/OK on the TV simultaneously to restart.	–
	Some functions do not work	●It is not a malfunction. Some functions (dark background) in the menu do not work depending on the situation.	–
Screen	Aspect ratio changes unintentionally	●Press ZOOM to return to your settings.	20
Picture	Poor picture quality	●Unnatural colour >>> Adjust COLOUR and BRIGHT-1. Check your COLOUR SYSTEM. ●Noise >>> Set to the following functions. PICTURE MODE : STANDARD DIGITAL VNR : AUTO (HIGH) Super DigiPure : MIN ●Dull picture >>> Set to the following functions. PICTURE MODE : BRIGHT DIGITAL VNR : MIN Super DigiPure : MAX	33 40 33 40 40 32 40 40
	Strange picture when using an external device	●If you connected S-Video output device, check the "S-IN" setting. ●If the top of the image is distorted, check the video signal quality itself. ●If movement appears unnatural when receiving a signal from a DVD player, etc. with 625p (progressive-scanning), change the output setting of the external device to 625i (interlace-scanning).	27 – –
Sound	Poor sound	●Adjust the BASS and TREBLE. ●If receiving a poor signal in "STEREO/ Ⅰ · Ⅱ", switch to MONO.	33 33

Troubleshooting (continued)

	Problem	Actions	page
HDMI	Wrong screen size	●Switch SIZE in HDMI SETTING to "1" or "2".	33
	No sound	●Switch AUDIO in HDMI SETTING to ANALOGUE or DIGITAL.	33
	Green and distorted screen	●Wait a little for the signal to stabilize when switching the signal format for an HDMI device.	–
Functions	Some inputs are skipped in the sub-picture	●DTV channels, EXT-4/EXT-5 inputs, and PC mode cannot be selected in the sub-picture.	–
Error message	"FEATURE NOT AVAILABLE"	●Is the T-V LINK compatible device connected to EXT-2? ●Is the SCART CABLE "Fully Wired"? ●Is the T-V LINK compatible device turned on? After confirming all the conditions above, press "OK" button again.	46 46 –
	"ACI ERROR"	●Press ◀ to start ACI again. If you still receive the "ACI ERROR" after numerous tries, press ▶ to cancel ACI.	–
	"NO RECORDING"	●A problem occurs at the recorder.	–
	"NO RECORDING POSSIBLE"	●The displayed video cannot be recorded.	–
	"NO RECORDING MEDIA PROBLEM"	●The recorder is not ready for recording. Check the videotape or DVD disc.	–
	"NO RECORDING DEVICE BUSY"	●The recorder is recording another programme, or is playing.	–
Screen	Black or white dots appear on the screen	●LCD panels use fine dots ("pixels") to display images. While more than 99.99% of these pixels function properly, a very small number of pixels may not light, or may light all the time. Please understand that this is not a malfunction.	–

Problem		Actions	page
DTV	An error message does not disappear	●Deleting a DTV channel may cause an error message to appear while other channels displayed. ➡ Register channels again in "Automatic Search"	39

CH/CC List

- To use the INSERT function (P. 16), find the CH/CC number corresponding to the TV's channel number from this table. If you want to know a particular TV channel's channel menu, look in TV listings magazines or contact the broadcaster.
- When the COUNTRY setting is UNITED KINGDOM, the CC number channels and channels from CH02 to CH12 cannot be received.

CH	Channel
CH 02	E2, IR A
CH 03	E3, IR B
CH 04	E4, IR C
CH 05	E5, IR D
CH 06	E6, IR E
CH 07	E7, IR F
CH 08	E8, IR G
CH 09	E9
CH 10	E10, IR H
CH 11	E11, IR J
CH 12	E12
CH 21	E21
CH 22	E22
CH 23	E23
CH 24	E24
CH 25	E25
CH 26	E26
CH 27	E27
CH 28	E28
CH 29	E29
CH 30	E30
CH 31	E31
CH 32	E32
CH 33	E33
CH 34	E34
CH 35	E35
CH 36	E36
CH 37	E37
CH 38	E38
CH 39	E39

CH	Channel
CH 40	E40
CH 41	E41
CH 42	E42
CH 43	E43
CH 44	E44
CH 45	E45
CH 46	E46
CH 47	E47
CH 48	E48
CH 49	E49
CH 50	E50
CH 51	E51
CH 52	E52
CH 53	E53
CH 54	E54
CH 55	E55
CH 56	E56
CH 57	E57
CH 58	E58
CH 59	E59
CH 60	E60
CH 61	E61
CH 62	E62
CH 63	E63
CH 64	E64
CH 65	E65
CH 66	E66
CH 67	E67
CH 68	E68
CH 69	E69

CC	Channel
CC 01	S1
CC 02	S2
CC 03	S3
CC 04	S4
CC 05	S5
CC 06	S6
CC 07	S7
CC 08	S8
CC 09	S9
CC 10	S10
CC 11	S11
CC 12	S12
CC 13	S13
CC 14	S14
CC 15	S15
CC 16	S16
CC 17	S17
CC 18	S18
CC 19	S19
CC 20	S20
CC 21	S21
CC 22	S22
CC 23	S23
CC 24	S24
CC 25	S25
CC 26	S26
CC 27	S27
CC 28	S28
CC 29	S29
CC 30	S30

CC	Channel
CC 31	S31
CC 32	S32
CC 33	S33
CC 34	S34
CC 35	S35
CC 36	S36
CC 37	S37
CC 38	S36
CC 39	S39
CC 40	S40
CC 41	S41
CC 75	X
CC 76	Y
CC 77	Z
CC 78	Z+1
CC 79	Z+2

Technical information

What is T-V LINK?

T-V LINK allows the TV to share information easily with a connected T-V LINK compatible device.
By using T-V LINK :

- You can send the ATV channel information programmed on the TV to the T-V LINK compatible device, so that both the TV and the external device have the same channel settings. When connecting a new external device, channel information is loaded into it, allowing channel setup to be completed very quickly. For more details, refer to the external device's manual.
- You can easily record the TV programme you are viewing on a T-V LINK compatible device by using the "DIRECT REC" feature. For more details, refer to the external device's manual.
- After timer-record setting, the TV will instruct the recorder to start and stop recording, via DIRECT REC.

What is ACI (Automatic Channel Installation)?

Some cable companies transmit a signal called ACI which contains information that allows TV channels to be registered automatically on your TV.
When an ACI signal is received, "ACI START/ACI CANCEL" appears in the "AUTO PROGRAM" screen.

PC Signals that can be displayed

Macintosh computers are not supported.
(Macintosh is a registered trademark of Apple Computer, Inc.)

- If the signal doesn't appear, check that the vertical frequency on the PC is set to 60Hz.

Resolution	640 x 480 (VGA)	1024 x 768 (XGA)
Vertical frequency (Hz)	60.0	60.0
Horizontal frequency (kHz)	31.5	42.0

Connect DVI devices

Connect a DVI device to EXT-5 (HDMI) using DVI-HDMI conversion cable. Connect analogue sound output of the DVI device to L and R terminals in EXT-4.

- Set AUDIO in HDMI SETTING to ANALOGUE or AUTO ➡ (P. 33)

If you accidentally cut the power cord

Attach a new plug following the steps below. If in doubt, contact your local retailer.

Important

- Never connect to the larger terminal marked with an "E", the safety earth symbol "⏚" or coloured green or green-and-yellow.
- The wires in the mains lead on this product are coloured with the following code:
  · Blue: Neutral wire (connect to the black terminal, or one marked "N")
  · Brown: Live wire (connect to the red terminal, or one marked "L")

Change the fuse in the plug

Open the plug as illustrated on the right.

- When replacing the fuse, always use a correctly rated and approved type and re-fit the fuse cover when finished.

If in doubt, contact your local retailer.



Licence

Manufactured under license from BBE Sound, Inc.
Licensed by BBE Sound, Inc. under USP4638258, 5510752 and 5736897.
BBE and BBE symbol are registered trademarks of BBE Sound, Inc.

Specifications

Main unit

Model	LT-32DS6BJ/SJ	LT-26DS6BJ/SJ
Broadcasting systems	CCIR, I	
Colour systems	PAL ·The EXT terminals also support the NTSC 3.58/4.43 MHz system.	
Channels and frequencies	●Analogue : E21-E69 (UNITED KINGDOM) IR A-J, E2-E12, E21-E69 (IRELAND) ●Digital : 474 MHz-850MHz (channel 21-68)	
Sound-multiplex systems	NICAM (I) system.	
Teletext systems	Analogue : FLOF (Fastext), WST (World Standard System). Digital : MHEG 5 UK profile	
Power requirements	AC 110 V - 240 V, 50/60Hz	
Audio output (Rated power output)	10 W + 10 W	
Speakers	6.6 cm round x 2	
Power consumption	152 W (standby : 2.6 W)	131 W (standby : 2.6 W)
Screen size (visible area size measured diagonally)	80 cm	66 cm
Dimensions (W x H x D : mm)	808 x 611 x 225 808 x 558.5 x 108 (without stand)	703 x 536.8 x 225 703 x 483 x 107 (without stand)
Weights	21.0 kg 17.2 kg (without stand)	18.0 kg 14.0 kg (without stand)
Accessories	(See "Check accessories", P. 5)	

●This TV has the CAM (Conditional Access Module) slot for watching pay-per-view.
Please note that the CAM and viewing card must be purchased separately.

Terminals / Connectors

Terminal name		Terminal type	Signal type (IN)	Signal type (OUT)
Input / Output terminals	EXT-1	Euroconnector x1 (SCART connector)	Composite video, S-video, Analog RGB, AUDIO L / R	TV out
	EXT-2	Euroconnector x1 (SCART connector)	Composite video, S-video, Analog RGB, AUDIO L / R	Dubbing out (S-VIDEO out is available only for DTV channels)
Input terminals	EXT-3	RCA connectors x 3, S-VIDEO connector x 1	Composite video, S-video AUDIO L / R	
	EXT-4	RCA connectors x 5	Analogue component (576i (625i) / 480i (525i), Progressive : 576p (625p) / 480p (525p), HD : 1080i (1125i), 720p (750p)) AUDIO L / R	
	EXT-5 (HDMI)	HDMI connector x 1	HDMI (576i (625i) / 480i (525i) / 576p (625p) / 480p (525p), 1080i (1125i), 720p (750p))	
	PC INPUT	D-SUB (15 pins) x 1	Analogue PC signal (P. 46)	
Output terminals	AUDIO OUT	RCA connectors x 2		Audio L / R
	Headphone	Stereo mini-jack x 1 (3.5 mm in diameter)		Headphone output

●We may change the design and specifications without notice.

JVC

For users in the UK :
If you have any problems setting up your new TV, please call the JVC Helpline on **0870 330 5000.**

For users in the Republic of Ireland :
If you have any problems setting up your new TV, please call the JVC Helpline on **1890-582500.**

©2005 Victor Company of Japan, Limited

0305 MKH-CR-MU